

East Ohio Valley Railway



24 / 7 / 365 Operations

12 Miles of Track

Interchanges with NS

150 Railcar Storage Spaces

286K load Capacity

EAST OHIO VALLEY RAILWAY

Class 3 Terminal Switching

- Terminal Switching
- In – Plant Switching
- Track maintenance and repair
- Railcar Storage
- Transloading Services



EAST OHIO VALLEY RAILWAY

900 Thompson Run Road
Monroeville PA, 15146
412-235-1973

www.transtarrail.com

Contacts

Matt O'Kray
mokray@transtarrail.com
630-423-2684

JW Burwinkel
jwburwinkel@transtarrail.com
412-584-6169