



24 / 7 / 365 Operations

42 Miles of Track

**Interchanges with
CPKC**

**2,000 Railcar Storage
Spaces**

286K load Capacity

TEXAS & NORTHERN RAILWAY

Class 3 Haulage Switching

- Terminal Switching
- In – Plant Switching
- Locomotive maintenance and repair
- Track maintenance and repair
- Railcar fleet and AAR repair
- Railcar Storage
- Trans loading Services



TEXAS & NORTHERN RAILWAY

900 Thompson Run Road
Monroeville PA, 15146
412-235-1973

www.transtarrail.com

Contacts

Matt O’Kray
mokray@transtarrail.com
630-423-2684

JW Burwinkel
jwburwinkel@transtarrail.com
412-584-6169