



**24 / 7 / 365 Operations**

**17 Miles of Track**

**Interchanges with  
NS & CSX**

**500 Railcar Storage  
Spaces**

**286K load Capacity**

# THE LAKE TERMINAL RAILROAD

## Class 3 Terminal Switching

- In – Plant Switching
- Locomotive maintenance and repair
- Track maintenance and repair
- Railcar fleet and AAR repair
- Railcar Storage
- Transloading Services



## THE LAKE TERMINAL RAILROAD

900 Thompson Run Road  
Monroeville PA, 15146  
412-235-1973

[www.transtarrail.com](http://www.transtarrail.com)

### Contacts

Matt O'Kray  
[mokray@transtarrail.com](mailto:mokray@transtarrail.com)  
630-423-2684

JW Burwinkel  
[jwburwinkel@transtarrail.com](mailto:jwburwinkel@transtarrail.com)  
412-584-6169